

DTC	P1335	CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION (DURING ENGINE RUNNING)
------------	--------------	---

CIRCUIT DESCRIPTION

Refer to DTC P0335 on page [05-76](#).

DTC No.	DTC Detecting Condition	Trouble Area
P1335	If conditions (a) through (c) are met: (a) NE \geq 1,000 rpm (b) NE signal is not detected for over 50 msec. (c) Not during cranking	<ul style="list-style-type: none"> • Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Crank angle sensor plate • ECM

WIRING DIAGRAM

Refer to DTC P0335 on page [05-76](#).

INSPECTION PROCEDURE

Refer to DTC P0335 on page [05-76](#).