DIFFERENTIAL PREPARATION

SST

\bigcirc	09223-15020	Oil Seal & Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09223-15030	Oil Seal & Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09223–46011	Crankshaft Front Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09308–00010	Oil Seal Puller	REAR DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09308–10010	Oil Seal Puller	OIL DIAPHRAGM SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09316-60011	Transmission & Transfer Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	(09316-00071)	Replacer "F"	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09325–20010	Transmission Oil Plug	OIL DIAPHRAGM SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09502-12010	Differential Bearing Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09506–35010	Differential Drive Pinion Rear Bearing Replacer	OIL DIAPHRAGM SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09518–36020	Rear Axle Hub Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY REAR(4WD)
	09550–55011	Differential Replacer Set	DIFFERENTIAL CARRIER ASSY REAR(4WD)

021DZ-01

(09550–05061)	Replacer "B"	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09554–22010	Differential Oil Seal Replacer	OIL DIAPHRAGM SEAL(4WD) REAR DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
09556–16011	Differential Drive Pinion Holding Tool	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09556–30010	Drive Pinion Front Bearing Remover	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09564–16020	Drive Pinion Lock Nut Wrench	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09564–32011	Differential Preload Adaptor	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09612–65014	Steering Worm Bearing Puller	DIFFERENTIAL CARRIER ASSY REAR(4WD)
(09612–01020)	Claw "B"	DIFFERENTIAL CARRIER ASSY REAR(4WD)
(09612–01050)	Hanger Pin with Nut	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09930-00010	Drive Shaft Nut Chisel	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09950-00020	Bearing Remover	DIFFERENTIAL CARRIER ASSY REAR(4WD)
09950-40011	Puller B Set	DIFFERENTIAL CARRIER ASSY REAR(4WD)
(09951–04020)	Hanger 200	DIFFERENTIAL CARRIER ASSY REAR(4WD)

69

	(09952–04010)	Slide Arm	DIFFERENTIAL	CARRIER	ASSY
	(0,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		REAR(4WD)	-	
	(09953–04020)	Center Bolt 150	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09954–04010)	Arm 25	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09955–04011)	Claw No.1	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09955–04061)	Claw No.6	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
S	(09957–04010)	Attachment	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09958–04011)	Holder	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	09950–60010	Replacer Set	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
0	(09951–00270)	Replacer 27	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
9	(09951–00370)	Replacer 37	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00460)	Replacer 46	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00490)	Replacer 49	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00530)	Replacer 53	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY

	(09951–00540)	Replacer 54	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00580)	Replacer 58	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00620)	Replacer 62	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09952–06010)	Adapter	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	09950–60020	Replacer Set No.2	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00680)	Replacer 68	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–00910)	Replacer 91	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	09950–70010	Handle Set	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	(09951–07100)	Handle 100	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
Q	(09951–07150)	Handle 150	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY

Recomended Tools

	09011–12301	Socket Wrench 30 mm	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
	09017–12301	Deep Socket Wrench 30 mm .	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY
A A A A A A A A A A A A A A A A A A A	09040–00011	Hexagon Wrench Set	DIFFERENTIAL REAR(4WD)	CARRIER	ASSY

PREPARATION - DIFFERENTIAL

(09043–20060) Socket Hexagon Wrench 6	DIFFERENTIAL CARRIER ASSY REAR(4WD)
(09043-20100) Socket Hexagon Wrench 10	DIFFERENTIAL OIL(4WD) DIFFERENTIAL CARRIER ASSY REAR(4WD)
(09043–30170) Straight Hexagon Wrench 17	DIFFERENTIAL CARRIER ASSY REAR(4WD)

Equipment

Dial indicator	
Pin punch	
Torque wrench	

Lubricant

Item	Capacity	Classification
Differential oil	0.5 liters (0.52 US qts, 0.44 lmp. qts)	Hypoid gear oil API GL–5 Above –18°C (0°F) SAE 90 Below –18°C (0°F) SAE 80W or 80W–90

SSM

"Seal Packing 1281," THREE BOND 1281 or equivalent (FIPG)	