













REAR SUSPENSION











PREPARATION

021CS-01



SST



	09023-00100	Union Nut Wrench 10 mm	STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD) REAR AXLE BEAM ASSY(FF)
	09325-20010	Transmission Oil Plug	STABILIZER BAR REAR(4WD)
	09632-36010	Steering Vane Pump Bearing Replacer	REAR SUSPENSION ARM ASSY NO.1 LH(4WD)
	09703-30010	Brake Shoe Return Spring Tool	STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD)
	09710-04101	Base	REAR AXLE BEAM ASSY(FF)
	09718-00010	Shoe Hold Down Spring Driver	STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD)
	09727-30021	Coil Spring Compressor	REAR SHOCK ABSORBER WITH COIL SPRING(4WD) REAR SHOCK ABSORBER WITH COIL SPRING(FF)
	09930-00010	Drive Shaft Nut Chisel	STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD)
	09950-40011	Puller B Set	REAR SUSPENSION ARM ASSY NO.1 LH(4WD) REAR AXLE BEAM ASSY(FF)
	(09951-04010)	Hanger 150	REAR SUSPENSION ARM ASSY NO.1 LH(4WD)
	(09951-04020)	Hanger 200	REAR AXLE BEAM ASSY(FF)
	(09952-04010)	Slide Arm	REAR SUSPENSION ARM ASSY NO.1 LH(4WD) REAR AXLE BEAM ASSY(FF)

PREPARATION - REAR SUSPENSION

	(09953-04010) Center Bolt 100	REAR SUSPENSION ARM ASSY NO.1 LH(4WD)
	(09953-04030) Center Bolt 200	REAR AXLE BEAM ASSY(FF)
	(09954-04010) Arm 25	REAR SUSPENSION ARM ASSY NO.1 LH(4WD)
	(09954-04020) Arm 100	REAR AXLE BEAM ASSY(FF)
	(09955-04051) Claw No.5	REAR SUSPENSION ARM ASSY NO.1 LH(4WD) REAR AXLE BEAM ASSY(FF)
	(09957-04010) Attachment	REAR SUSPENSION ARM ASSY NO.1 LH(4WD) REAR AXLE BEAM ASSY(FF)
	(09958-04011) Holder	REAR SUSPENSION ARM ASSY NO.1 LH(4WD) REAR AXLE BEAM ASSY(FF)
	09950-60010 Replacer Set	REAR AXLE BEAM ASSY(FF)
	(09951-00620) Replacer 62	REAR AXLE BEAM ASSY(FF)
	(09951-00630) Replacer 63	REAR AXLE BEAM ASSY(FF)

Recommended Tools

	09011-12301 Socket Wrench 30 mm	STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD)
	09040-00011 Hexagon Wrench Set	REAR SHOCK ABSORBER WITH COIL SPRING(FF)

	(09043-20050) Socket Hexagon Wrench 5	REAR SHOCK ABSORBER WITH COIL SPRING(4WD) REAR SUSPENSION ARM ASSY NO.1 LH(4WD) STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD)
	(09043-20060) Socket Hexagon Wrench 6	REAR SHOCK ABSORBER WITH COIL SPRING(4WD) STABILIZER BAR REAR(4WD) UPPER CONTROL ARM ASSY(4WD) REAR SHOCK ABSORBER WITH COIL SPRING(FF)

Equipment

Torque wrench	
Dial indicator magnetic base	
Wheel balancer	
Tire pressure gauge	
Alignment tester	
Toe-in gauge	
Camber-caster-kingpin gauge	
Drill	