


FAN AND GENERATOR V BELT (1ZZ-FE)

REPLACEMENT

1400D-02

1. REMOVE ENGINE UNDER COVER RH



2. REMOVE FAN AND GENERATOR V BELT

- (a) Turn the V-ribbed belt tensioner slowly clockwise and loosen it. Then, remove the fan and generator V belt and put back the V-ribbed belt tensioner little by little and fix it quietly.