OUTPUT SHAFT ASSY (C60) 41088-01 **COMPONENTS** 1st Gear **Thrust Washer** Pin or Ball **Output Shaft Front** Bearing Snap Ring **Output Shaft** 1st Gear **Thrust Washer Output Shaft Front Bearing Reverse Gear** Transmission Clutch Hub No.1 Synchronizer 1st Gear Needle Ring Set No.2 **Roller Bearing** 1st Gear Synchronizer 2nd Gear Needle Clutch Hub No.1 Ring No.1 **Roller Bearing** Shaft Snap Ring 6 Synchromesh Shifting Key Spring Synchromesh 2nd Gear Bearing Spacer Shifting Key 2nd Gear 3rd Driven Gear **Output Gear Spacer Output Shaft Center Bearing** 4th Driven Gear Apply MP grease D07356