



# HEADLAMP DIMMER SWITCH ASSY REPLACEMENT

650HF-01



- 1. REMOVE STEERING COLUMN COVER LWR**
  - (a) Remove 3 screws and steering column cover LWR.



- 2. REMOVE HEADLAMP DIMMER SWITCH ASSY**
  - (a) Disconnect the connector.
  - (b) Release the claw and pull out the head light dimmer switch assy.