

WIPER AND WASHER SYSTEM

PROBLEM SYMPTOMS TABLE

6607C-02

1. WIPER AND WASHER SYSTEM

Symptom	Suspect Area	See page
Front wipers do not operate.	<ol style="list-style-type: none"> 1. IG1 relay 2. WIPER fuse 3. Front wiper switch 4. Wire harness 	<p>–</p> <p>–</p> <p>66-3</p> <p>–</p>
Front wipers do not operate in LO or HI.	<ol style="list-style-type: none"> 1. Front wiper switch 2. Front wiper motor 3. Wire harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Front wipers do not operate in INT.	<ol style="list-style-type: none"> 1. Front wiper switch 2. Front wiper motor 3. Wire harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Front washer motor does not operate.	<ol style="list-style-type: none"> 1. WIPER fuse 2. Front washer switch 3. Front washer motor 4. Wire harness 	<p>–</p> <p>66-3</p> <p>66-2</p> <p>–</p>
Front wipers do not operate when washer switch is in the ON position.	<ol style="list-style-type: none"> 1. Front wiper switch 2. Front wiper motor 3. Wire harness 	<p>66-3</p> <p>66-3</p> <p>–</p>
Washer fluid is not injected.	<ol style="list-style-type: none"> 1. Washer hose and nozzle 	<p>–</p>
<ul style="list-style-type: none"> • When the wiper switch is OFF, the wiper blade does not retract or the retract position is wrong. • The wiper blade is in contact with the body. 	<ol style="list-style-type: none"> 1. Wiper motor (Wiper arm and blade set position) 	<p>66-11</p>