

# WASHER NOZZLE

## ADJUSTMENT

6607B-01

### 1. INSPECT WASHER NOZZLE

- (a) With the engine running, check that the point where the washer fluid hits the windshield and the rear window is within the range indicated by the hatched line.



