



# WINDSHIELD WIPER SWITCH ASSY REPLACEMENT

6607A-01



1. **REMOVE STEERING COLUMN COVER LWR**
  - (a) Remove 3 screws and steering column cover LWR.



2. **REMOVE WINDSHIELD WIPER SWITCH ASSY**
  - (a) Disconnect the connector of the windshield wiper switch.
  - (b) Release the claw and pull out the windshield wiper switch assy as shown in the illustration.

**NOTICE:**

**Pressing the claw hard breaks the claw.**