RADIO WIRE SUB ASSY


REPLACEMENT

HINT:


COMPONENTS: See page 67-2

1. REMOVE INSTRUMENT PANEL SUB-ASSY UPPER (See page 71–10) HINT:

Refer to the instructions for removal of the instrument panel sub-assy upper.



- REMOVE RADIO WIRE SUB ASSY
- (a) Disconnect the connector.
- (b) Remove the 3 clamps and radio wire sub assy.



3. INSTALL INSTRUMENT PANEL SUB-ASSY UPPER (See page 71–10)

670EH-01