

# POWER POINT SOCKET ASSY NO.2


## REPLACEMENT

670EP-01

HINT:

COMPONENTS: See page 67-2

1. REMOVE FLOOR SHIFT SHIFT LEVER KNOB SUB-ASSY (M/T TRANSAXLE)  
(See page 71-10)
2. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY CTR (See page 71-10)



3. REMOVE POWER POINT SOCKET ASSY NO.2
  - (a) Release the 2 fitting claws, remove the power point socket assy No.2.