


DISC PLAYER CHANGER REPLACEMENT

670EE-01

HINT:

COMPONENTS: See page 67-2

1. **DISCONNECT BATTERY NEGATIVE TERMINAL** (See page 72-6)
2. **REMOVE FRONT SEAT (PASSENGER SEAT POSITION)** (See page 72-6)



3. **REMOVE DISC PLAYER CHANGER**
 - (a) Disconnect the connector.
 - (b) Remove the 3 bolts and disc player changer.

4. **INSTALL FRONT SEAT (PASSENGER SEAT POSITION)** (See page 72-6)