
## POWER SOURCE



68038-01

Engine Room Relay Block Assy		
C	FUSE	
$\begin{bmatrix} A \\ B \\ 123 \\ 4 \\ 5 \\ 6 \end{bmatrix}$	1, – 2, HEAD RH LWR 3, HEAD LH LWR 4, – 5, HEAD MAIN 6, ALT–S 7, EFI 8, HAZARD 9, HORN 10, DOME 11, MAIN 12, – 13, – 14, ALT	10 A 10 A 40 A 5 A 15 A 10 A 10 A 15 A 30 A
7 8 9 9 10 11 C 12 13 24 24 25	15, HEAD RH UPR 16, HEAD LH UPR 17, ABS No. 2 18, RDI FAN 19, ABS No. 1 20, FOG 21, – 22, – 23, SPARE 24, SPARE 25, SPARE	10 A 10 A 40 A 40 A 30 A 15 A 10 A 15 A 30 A
	RELAY A, HEAD B, M/G CLT C, DIMMER D, EFI	E, FOG F, HORN G, FAN No. 2 H, FAN No. 1

P

132288

Instrument Panel 1 2 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23	Junction Blo	ock Assy		
FUSE				RELAY
1, HEATER 2, DEFOG 3, POWER 4, A/C 5, M-HTR/DEF I-UP 6, AM2 7, RR WIPER 8, WASHER 9, WIPER 10, ECU-IG 11, GAUGE 12, -	40 A 30 A 30 A 10 A 15 A 15 A 15 A 25 A 10 A 10 A	13, – 14, CIG 15, – 16, AM1 17, ECU–B 18, OBD 19, DOOR 20, P/POINT 21, TAIL 22, STOP 23, INV	15 A 25 A 10 A 7.5 A 25 A 15 A 15 A 15 A 15 A	A, ST B, DEF C, C/OPN D, P/W E, IG 1

Ρ

