

**PROBLEM SYMPTOMS TABLE**

Symptom	Suspected Area	See page
Horn does not sound	2. HORN fuse	-
	3. Horn button switch	-
	4. Low pitched horn	<a href="#">69-3</a>
	5. HORN relay	<a href="#">69-3</a>
	6. Wire harness	-