

WIRELESS DOOR LOCK CONTROL SYSTEM

730B8-01

PRECAUTION

1. NOTICES WHEN CHECKING

- (a) The wireless door lock remote control operates only when the following 3 conditions are satisfied.
 - (1) All the doors are closed. However, doors can be unlocked even when any of the doors is opened.
 - (2) The key is not inserted in the ignition key cylinder. However, doors can be unlocked.
 - (3) The power door lock operates normally.
- (b) The wireless door lock remote control operational area varies with the situations.
 - (1) The operational area varies with the operators or the ways to hold the transmitter.
 - (2) The operational area will be narrowed down in some places due to the body configuration and the influence of the surrounding environment, or the remote control will not operate partially.
 - (3) Because of using faint electric wave, in case that there is a strong electric wave or noise in the frequency used area, the operational area may be narrowed down or the remote control may not be operated.
 - (4) When the battery is consumed, the operational area is narrowed down or the remote control is not operated.

HINT:

Leaving the door control transmitter on the exposed place to the direct sun light, such as on the instrument panel, may cause the battery wear or a trouble.