SHIFT & SELECT LEVER SHAFT ASSY (C59)

4108C–01

COMPONENTS




Shift & Select Lever Shaft
◆ Control Shaft Cover Oil Seal
Control Shaft Cover
Snap Ring
Shift & Select Lever Shaft Boot
Compression Spring
Select Inner Lever
Shift Inter Lock Plate
Shift Lever Inner No.2
Select Spring Seat No.2
Slotted Spring Pin
Slotted Spring Pin
Slotted Spring Pin
E–ring
Compression Spring
Shift Inner Lever No.2
◆ Non–reusable part
P
Apply MP grease
D12109