

HOW TO TROUBLESHOOT ECU CONTROLLED SYSTEMS

01034-04

GENERAL INFORMATION

A large number of ECU controlled systems are used in this vehicle. In general, the ECU controlled system is considered to be a very intricate system requiring high level of technical knowledge and expert skill to troubleshoot. The fact is, however, that if you proceed to inspect the circuits one by one, troubleshooting of these systems is not complex. If you have adequate understanding of the system and basic knowledge of electricity, accurate diagnosis and necessary repair can be performed to locate and fix the problem. This manual is designed through emphasis of the above standpoint to help service technicians perform an accurate and effective troubleshooting, and is compiled for the following major ECU controlled systems.

The troubleshooting procedure and how to make use of it are described on the following pages.

System	Page
1. SFI System (1ZZ-FE)	05-1
2. SFI System (2ZZ-GE)	05-153
3. ABS with EBD System	05-313
4. Electronic Controlled Automatic Transaxle [ECT] (A246E)	05-371
5. Electronic Controlled Automatic Transaxle [ECT] (U240E)	05-419
6. Electronic Controlled Automatic Transaxle [ECT] (U341F)	05-484
7. Supplemental Restraint System	05-540
8. Audio System	05-712
9. Navigation System	05-749
10. Combination Meter	05-814
11. Power Door Lock Control System	05-844
12. Wireless Door Lock Control System	05-859
13. TOYOTA Vehicle Intrusion Protection System	05-874
14. Cruise Control System	05-916

FOR USING OBDII SCAN TOOL OR HAND-HELD TESTER

HINT:

- Before using the scan tool or tester, the scan tool's instruction book or tester's operator manual should be read thoroughly.
- If the scan tool or tester cannot communicate with the ECU controlled systems when you have connected the cable of the scan tool or tester to the DLC3, turned the ignition switch ON and operated the scan tool, there is a problem on the vehicle side or tool side.
 - (1) If the communication is normal when the tester is connected to another vehicle, inspect the diagnosis data link line (Bus \oplus line) or ECU power circuit of the vehicle.
 - (2) If the communication is still impossible when the tester is connected to another vehicle, the problem is probably in the tester itself, so perform the Self Test procedures outlined in the Tester Operator's Manual.